




UNI-SWC.3 Universal Steering Wheel Control for CAN-Bus & Resistive Vehicles

**New and Updated Vehicle
Applications**



INSTRUCTION MANUAL

About


The Connects2 UNI-SWC.3 covers a wide range of both CAN-Bus and analogue vehicles, allowing steering wheel control retention with almost every steering wheel control compatible head unit on the market. A Connects2 head unit specific patch lead (sold separately) is required with this interface.

Installation


- 1: Remove and disconnect the original head unit.
- 2: Connect the aftermarket patch lead to the UNI-SWC.3 interface and to the aftermarket head unit steering wheel control input.
- 3: Set the correct dipswitch settings on the UNI-SWC.3 (see Fig 2.) according to the vehicle it is being fitted into. See car specific diagrams for further information.
4. Install into the vehicle using Interface Connections (Fig 1.) and the car specific wiring information overleaf.

NOTE: Car manufacturers can change wiring specifications without notice. Ensure that the correct wires are located before commencing installation.

Interface Connections



Dipswitch Settings



Set the dipswitches 1-7 according to the car specific settings overleaf.

Set dipswitch 8 to ON when fitting the UNI-SWC.3 interface with a Pioneer head unit.

Ensure dipswitch 8 is set to OFF when fitting with a Sony head unit.

Car Specific Dipswitch Settings

Manufacturer	Model	Start Year	End Year	Phone Button Support	CAN / Analogue	Dipswitch Setting							Outputs				
						1	2	3	4	5	6	7	Reverse	Speed	Park Brake		
Alfa Romeo	147	2000	2007	N	Analogue		ON	ON	ON	ON	ON						
	147	2007	2010	N	CAN		ON	ON	ON		ON		YES	YES	YES		
	156	2000	2007	N	Analogue		ON	ON	ON	ON	ON						
	159	2005	2011	Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES		
	4C/Mito/Giulietta	2013		Y	CAN- Open Dash	ON	ON	ON	ON	ON	ON		YES	YES	YES	YES	
	4C/Mito/Giulietta	2013		Y	CAN TYPE1		ON	ON	ON	ON	ON		YES	YES	YES	YES	
	4C/Mito/Giulietta	2013		Y	CAN TYPE2	ON		ON	ON	ON	ON		YES	YES	YES	YES	
	4C/Mito/Giulietta	2013		Y	CAN TYPE3			ON	ON	ON	ON		YES	YES	YES	YES	
	Brera	2005	2010	Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES	YES	
	Giulietta	2010	2014	Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES	YES	
	GT	2004	2008	N	Analogue		ON	ON	ON	ON		ON					
GT	2008	2010	N	CAN		ON	ON	ON		ON	ON	YES	YES	YES	YES		
Mito	2008	2014	Y	CAN		ON	ON	ON	ON	ON	ON	YES	YES	YES	YES		
Audi	A1	2010		Y	CAN												
	A3	2003	2012	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	A4	2001	2005	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	A4	2005	2015	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	A6	2004	2011	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	TT	2003	2006	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	TT	2006	2013	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
BMW	1 Series	2004	2013	Y	IBUS	ON		ON	ON	ON	ON						
	3 Series	1998	2005	Y	IBUS	ON	ON		ON	ON	ON						
	3 Series	2005	2012	Y	CAN	ON	ON		ON	ON	ON		YES	YES	YES	YES	
	5 Series	1996	2004	Y	IBUS	ON		ON	ON	ON	ON						
	5 Series	2004	2010	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	6 Series	2003	2010	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	7 Series	1994	2001	Y	IBUS	ON		ON	ON	ON	ON						
	7 Series	2001	2008	Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	Mini	2001	2006	Y	IBUS	ON		ON	ON	ON	ON						
	Mini	2006	2012		CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	X3	2004	2010	Y	IBUS	ON		ON	ON	ON	ON						
	X5	2000	2006	Y	IBUS	ON		ON	ON	ON	ON						
	Z4	2002		Y	IBUS	ON		ON	ON	ON	ON						
Z4	2009		Y	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES		
Chery	Tiggo	2013		N	Analogue			ON	ON	ON							
Chrysler	Delta	2011	2014	Y	CAN		ON	ON	ON	ON	ON						
Citroen	Berlingo	2008		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	C1	2014		Y	Analogue	ON			ON	ON	ON						
	C2	2005	2009	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	C3	2006		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	C3 Picasso	2009		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	C4	2004	2010	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	C4 Aircross	2014		Y	Analogue	ON	ON			ON	ON						
	C5	2005	2008	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	C8	2005	2014	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	Dispatch	2007		N	Analogue		ON	ON	ON		ON	ON					
	DS3	2009		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	Evasion	1996	2002	N	Analogue		ON	ON	ON		ON	ON					
	Jumper	2006	2008	N	CAN		ON	ON	ON		ON	ON	YES	YES	YES	YES	
	Jumper	2008	2013	N	CAN		ON	ON			ON	ON	YES	YES	YES	YES	
	Jumper	2014		Y	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	Nemo	2007		Y	CAN		ON	ON	ON		ON	ON					
	Relay	2006	2008	N	CAN		ON	ON	ON		ON	ON	YES	YES	YES	YES	
Relay	2006	2014	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES		
Relay	2007		N	Analogue		ON	ON	ON		ON	ON						
Synergie	1996	2002	N	Analogue		ON	ON	ON		ON	ON						
Chevrolet	Astra	1998	2011	N	Analogue		ON	ON		ON	ON	ON					
	Aveo	2002	2011	Y	Analogue			ON	ON		ON	ON					
	Captiva	2006	2011	Y	Analogue			ON	ON		ON	ON					
	Celta	2002	2010	N	Analogue				ON		ON	ON					
	Colorado	2012	2014	Y	Analogue	ON	ON				ON	ON					
	Corsa Classic	2002	2010	N	Analogue				ON		ON	ON					
	S10	2012		Y	Analogue	ON	ON				ON	ON					
	Sonic	2013		Y	Analogue				ON	ON			ON				
	Spark	2010	2015	Y	Analogue					ON	ON		ON				
	Spark	2013	2015	Y	Analogue					ON	ON		ON				
	Tracker		2009	N	Analogue	ON				ON		ON					
	Urban	1998	2011	N	Analogue				ON		ON	ON	ON				
	Vectra	2005	2011	N	Analogue				ON		ON	ON	ON				
Viva	1998	2011	N	Analogue				ON		ON	ON	ON					
Daewoo	Winstorm	2008	2011	Y	Analogue				ON	ON	ON	ON					

Car Specific Dipswitch Settings

Manufacturer	Model	Start Year	End Year	Phone Button Support	CAN / Analogue	Dipswitch Setting							Outputs		
						1	2	3	4	5	6	7	Reverse	Speed	Park Brake
DAF	CF (TYPE 1)	2017		N	CAN	ON	ON	ON	ON	ON			YES	YES	YES
	CF (TYPE 2)	2017		N	CAN		ON	ON	ON	ON			YES	YES	YES
	XF (TYPE 1)	2017		N	CAN	ON	ON	ON	ON	ON			YES	YES	YES
	XF (TYPE 2)	2017		N	CAN		ON	ON	ON	ON			YES	YES	YES
Dodge	RAM ProMaster	2014		Y	CAN						ON		YES	YES	YES
	500	2007		Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES
Fiat	500L	2012		Y	CAN- Open Dash	ON	ON	ON	ON	ON			YES	YES	YES
	500L	2012		Y	CAN-TYPE1		ON	ON	ON	ON			YES	YES	YES
	500L	2012		Y	CAN TYPE2	ON		ON	ON	ON			YES	YES	YES
	500L	2012		Y	CAN TYPE3			ON	ON	ON			YES	YES	YES
	Bravo	2007	2014	Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES
	Doblo	2009	2015	Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES
	Ducato	2011	2014	Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES
	Ducato	2006	2008	N	CAN							ON	YES	YES	YES
	Ducato	2008	2014	N	CAN							ON	YES	YES	YES
	Ducato	2012	2014	N	CAN							ON			
	Ducato	2014	2014	Y	CAN							ON			
	Ducato	2007	2011	N	Analogue		ON					ON			
	Ducato	2015		Y	CAN-Open Dash	ON	ON	ON	ON	ON			YES	YES	YES
	Ducato	2015		Y	CAN-TYPE1		ON	ON	ON	ON			YES	YES	YES
	Ducato	2015		Y	CAN TYPE2	ON		ON	ON	ON			YES	YES	YES
	Ducato	2015		Y	CAN TYPE3			ON	ON	ON			YES	YES	YES
	Florino	2007		Y	CAN		ON	ON	ON	ON	ON				
	Idea	2006	2012	Y	CAN		ON	ON	ON	ON	ON				
	Multipla	2004		N	Analogue		ON					ON			
	Panda	2007	2012	N	CAN		ON	ON			ON	ON			
	Panda	2004	2007	N	Analogue		ON					ON			
	Punto	2005		Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES
	Qubo	2007		Y	CAN		ON	ON	ON	ON	ON				
	Ritmo	2007	2014	Y	CAN		ON	ON			ON	ON			
	Sedici	2006	2014	N	Analogue							ON			
	Stilo	2001	2007	Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES
	Ford	B-Max	2012		N	CAN/Analogue		ON			ON				
		C-Max	2003	2010	N	CAN/Analogue		ON	ON	ON	ON		YES	YES	YES
C-Max		2010		N	CAN/Analogue			ON		ON	ON				
Ecosport		2013		N	CAN/Analogue					ON					
Escape		2013		N	CAN/Analogue		ON			ON					
Everest		2015		N	CAN/Analogue		ON			ON					
F150		2004	2008	N	Analogue			ON			ON				
Falcon AU Series 2&3		2000	2002	N	Analogue							ON			
Fiesta		2001		N	Analogue			ON			ON				
Fiesta		2002	2005	N	Analogue			ON			ON				
Fiesta		2005	2008	N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES
Fiesta		2012		N	CAN/Analogue			ON			ON				
Fiesta		2013		N	Analogue			ON			ON				
Focus		1998	2004	N	Analogue			ON			ON				
Focus		2004	2011	N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES
Focus		2011		N	CAN/Analogue			ON			ON				
Fusion		2002	2005	N	Analogue			ON			ON				
Fusion		2005	2012	N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES
Galaxy		2000	2006	N	Analogue			ON			ON				
Galaxy		2006		N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES
Kuga		2008	2012	N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES
Kuga		2013		N	CAN/Analogue						ON				
Mondeo		2000	2004	N	Analogue			ON			ON				
Mondeo		2007	2014	N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES
Puma		1997	2002	N	Analogue			ON			ON				
Ranger		2012		N	CAN/Analogue			ON			ON				
Ranger		2013		N	CAN/Analogue	ON	ON				ON				
Ranger		2015		N	CAN			ON			ON				
S-Max		2006		N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES
Taurus		2008	2012	N	CAN/Analogue			ON			ON				
Transit		2000	2006	N	Analogue			ON			ON				
Transit		2006	2013	N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES
Transit		2013		N	Analogue			ON			ON				
Transit		2015		N	CAN		ON				ON				
Transit Custom	2012	2016	N	CAN/Analogue			ON			ON					
Transit Custom	2015		N	CAN			ON			ON					
Transit Connect	2004	2013	N	CAN/Analogue		ON	ON	ON	ON	ON		YES	YES	YES	
Transit Connect	2013		N	CAN/Analogue			ON			ON					
Great Wall	Steed	2011		N	Analogue	ON		ON		ON	ON				
	Wingle	2011		N	Analogue	ON		ON		ON	ON				
	H6	2012		N	Analogue	ON					ON				

Car Specific Dipswitch Settings

Manufacturer	Model	Start Year	End Year	Phone Button Support	CAN / Analogue	Dipswitch Setting							Outputs			
						1	2	3	4	5	6	7	Reverse	Speed	Park Brake	
Holden	Barina	2000	2005	N	Analogue			ON		ON	ON	ON				
	Captiva	2008	2014	Y	Analogue			ON	ON		ON	ON				
	Commodore VT-VX	1997	2002	N	Analogue	ON	ON			ON	ON	ON				
	Commodore VY-VZ	2002	2007	N	Analogue			ON			ON	ON				
Astra, Barina, Vectra		2004	N	Analogue												
Harley Davidson	Street Glide	2015		N	CAN		ON	ON		ON	ON					
Honda	Amaze	2012		N	Analogue	ON	ON	ON		ON	ON	ON				
	City	2008	2013	N	Analogue	ON	ON	ON		ON	ON	ON				
	City	2014		Y	Analogue	ON	ON				ON	ON				
	Civic	2005	2012	N	Analogue	ON	ON	ON		ON	ON	ON				
	Civic	2012		Y	CAN	ON		ON				ON	YES	YES	YES	
	CR-V	2005	2007	N	Analogue	ON		ON		ON	ON	ON				
	CR-V	2007	2009	N	Analogue	ON	ON	ON		ON	ON	ON				
	CR-V	2012		Y	CAN	ON		ON				ON	YES	YES	YES	
	Fit	2014		Y	Analogue	ON	ON			ON	ON	ON				
	HR-V	2014		Y	Analogue	ON	ON				ON	ON				
	Jazz	2005	2008	N	Analogue				ON		ON	ON				
	Jazz	2014		Y	Analogue	ON	ON				ON	ON				
	S2000	2001		N	Analogue	ON		ON		ON	ON	ON				
	S2000	2005	2009	N	Analogue	ON	ON	ON		ON	ON	ON				
Hyundai	Azera	2011		Y	Analogue					ON	ON					
	Elantra	2011		Y	Analogue					ON	ON					
	i10	2009	2013	Y	Analogue					ON	ON					
	i10	2014		Y	Analogue						ON	ON				
	i20	2009	2015	Y	Analogue					ON	ON					
	i20	2015		Y	Analogue						ON	ON				
	i30	2007	2009	Y	Analogue						ON	ON				
	i30	2009	2012	Y	Analogue						ON	ON				
	i30	2012		Y	Analogue							ON	ON			
	i30	2007	2013	Y	Analogue						ON	ON				
	i40	2011		Y	Analogue						ON	ON				
	i40	2012		Y	Analogue						ON	ON				
	i45	2009		Y	Analogue						ON	ON				
	i800	2007		Y	Analogue						ON	ON				
	ix20	2010		Y	Analogue						ON	ON				
	ix35	2010		Y	Analogue						ON	ON				
	ix45	2013		Y	Analogue						ON	ON				
	Santa Fe	2006	2010	Y	Analogue						ON	ON				
	Santa Fe	2010	2013	Y	Analogue						ON	ON				
Santa Fe	2013		Y	Analogue						ON	ON					
Sonata	2008	2010	Y	Analogue						ON	ON					
Tucson	2010		Y	Analogue						ON	ON					
Isuzu	D-Max	2012		Y	Analogue	ON	ON			ON	ON					
	MU-X	2014		Y	Analogue	ON	ON			ON	ON					
Iveco	Daily	2014		Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES	
	Daily	2019		Y	LIN BUS											
JAC Motors	J3	2013		N	Analogue	ON	ON		ON			ON				
Jaguar	XJ8	1998	2003	Y	Analogue			ON		ON	ON					
	S Type	1999	2002	N	Analogue				ON		ON	ON				
	X Type	2001	2009	Y	Analogue	ON					ON	ON				
Kia	Cee'd	2007	2009	Y	Analogue	ON	ON	ON	ON	ON	ON					
	Cee'd	2009	2012	Y	Analogue	ON	ON	ON	ON	ON	ON					
	Cee'd	2013		Y	Analogue	ON	ON	ON	ON	ON	ON					
	Cee'd	2012		Y	Analogue					ON	ON					
	Optima	2014		Y	Analogue						ON	ON				
	Picanto	2011		Y	Analogue	ON	ON	ON	ON		ON	ON				
	Rio	2011		Y	Analogue	ON	ON	ON	ON		ON	ON				
	Sorento	2009	2011	Y	Analogue	ON	ON	ON	ON	ON	ON					
	Sorento	2015		N	CAN	ON	ON	ON			ON		YES	YES	YES	
	Carnival	2015		N	CAN	ON	ON	ON			ON		YES	YES	YES	
	Soul	2009	2011	Y	Analogue	ON	ON	ON	ON	ON	ON					
	Soul	2012		Y	Analogue	ON	ON	ON	ON	ON	ON					
Sportage	2010		Y	Analogue	ON	ON	ON	ON	ON	ON						
Venga	2009		Y	Analogue	ON	ON	ON	ON	ON	ON						
Lancia	Delta	2009		Y	CAN		ON	ON		ON	ON					
Land Rover	Discovery	2001	2004	N	Analogue						ON	ON				
	Discovery	2001	2004	N	Analogue						ON	ON				
	Discovery	2006	2014	Y	CAN						ON	ON	YES		YES	
	Freelander	2001	2003	N	Analogue						ON	ON				
	Freelander	2006	2014	Y	CAN						ON	ON	YES		YES	
Range Rover Sport	2005	2013	Y	CAN						ON	ON	YES		YES		
Lexus	Lexus GS Series	2003	2009	Y	Analogue	ON	ON	ON		ON	ON					

Car Specific Dipswitch Settings

Manufacturer	Model	Start Year	End Year	Phone Button Support	CAN / Analogue	Dipswitch Setting							Outputs				
						1	2	3	4	5	6	7	Reverse	Speed	Park Brake		
Lifan Motors	620	2009		N	Analogue	ON											
	720	2012		N	Analogue	ON	ON	ON	ON	ON	ON						
Mahindra	Scorpio	2006		Y	Analogue	ON	ON	ON	ON	ON							
Mazda	2	2007		N	Analogue		ON	ON		ON							
	6	2007	2009	N	CAN/Analogue		ON			ON	ON	YES	YES	YES			
	3	2004	2008	N	CAN/Analogue		ON	ON	ON	ON	ON	YES	YES	YES			
	CX-7	2008	2012	N	CAN/Analogue		ON			ON	ON	YES	YES	YES			
	CX-9	2007	2015	N	CAN/Analogue		ON			ON	ON	YES	YES	YES			
Mercedes	A-Class	2004	2012	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	B Class	2005	2011	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	C Class	2001	2004	N	CAN		ON			ON	ON	ON	YES	YES	YES		
	C Class	2000	2007	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	C Class	2007	2015	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES		
	CLK	2001	2004	N	CAN		ON		ON		ON		YES	YES	YES		
	E Class	2002	2009	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	ML	2005	2011	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	R Class	2006	2013	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	SLK	2004	2011	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	Sprinter	2006		Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	Sprinter	2018		Y	CAN	ON				ON	ON	ON	YES	YES	YES		
	Viano	2004	2015	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	Vito	2004	2015	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	Vito	2004	2015	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
	Vito	2015		Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES		
	Vivano	2004	2015	Y	CAN	ON		ON	ON	ON	ON	ON	YES	YES	YES		
Mitsubishi	ASX	2010		Y	Analogue		ON	ON	ON	ON	ON						
	Attrage	2015		Y	Analogue		ON	ON	ON	ON	ON						
	L200	2015		Y	Analogue		ON	ON		ON	ON						
	Lancer	2007	2010	Y	Analogue	ON			ON	ON	ON						
	Lancer	2010		Y	Analogue		ON	ON		ON	ON						
	Mirage	2013		Y	Analogue		ON	ON		ON	ON						
	Outlander	2007	2010	Y	Analogue	ON			ON	ON	ON						
	Outlander	2010	2013	Y	Analogue		ON	ON		ON	ON						
	Outlander	2013		Y	CAN/Analogue	ON			ON		ON						
	Pajero	2013		Y	Analogue		ON	ON		ON	ON						
	RVR	2010		Y	Analogue		ON	ON		ON	ON						
	Shogun	2013		Y	Analogue		ON	ON		ON	ON						
	Space Star	2015		Y	Analogue		ON	ON		ON	ON						
	Triton	2015		Y	Analogue		ON	ON		ON	ON						
Nissan	350z	2003		N	Analogue	ON	ON	ON		ON	ON						
	Almera	2000	2006	N	Analogue	ON	ON		ON	ON	ON						
	Cube	2009		Y	Analogue	ON		ON	ON		ON						
	Evalia	2013		Y	Analogue	ON		ON	ON		ON						
	Frontier	2009		Y	Analogue	ON		ON	ON		ON						
	Juke	2010		Y	Analogue	ON		ON	ON		ON						
	March	2010		Y	Analogue	ON		ON	ON		ON						
	Micra	2007	2010	Y	Analogue			ON		ON	ON						
	Micra	2010		Y	Analogue	ON		ON	ON		ON						
	Navara	2006		N	Analogue	ON	ON	ON		ON	ON						
	Navara	2009		Y	Analogue	ON		ON	ON		ON						
	Navara	2010		Y	Analogue			ON		ON	ON						
	Note	2009	2012	Y	Analogue	ON	ON	ON	ON		ON						
	Note	2012		Y	Analogue	ON	ON	ON	ON		ON						
	NV200	2013		Y	Analogue	ON		ON	ON		ON						
	Pathfinder	2013		Y	Analogue	ON		ON	ON		ON						
	Primera	2013	2007	N	Analogue	ON	ON	ON		ON	ON						
	Pulse	2011		Y	Analogue	ON		ON	ON		ON						
	Qashqai	2007	2013	Y	Analogue			ON		ON	ON						
	Quest	2010		Y	Analogue	ON		ON	ON		ON						
	Sentra	2013		Y	Analogue	ON		ON	ON		ON						
	Sunny	2012		Y	Analogue	ON		ON	ON		ON						
	Terrano	2001	2006	N	Analogue	ON	ON	ON		ON	ON						
	Tilda	2007	2014	Y	Analogue	ON	ON	ON		ON	ON						
	Titan	2009		Y	Analogue	ON		ON	ON		ON						
	Versa	2008		Y	Analogue	ON		ON	ON		ON						
	Xterra	2009		Y	Analogue	ON		ON	ON		ON						
X-Trail	2001		N	Analogue	ON	ON	ON		ON	ON							
X-Trail	2001	2008	N	Analogue	ON	ON	ON		ON	ON							
X-Trail	2009	2014	Y	Analogue			ON		ON	ON							
X-Trail	2013		N	Analogue		ON	ON		ON	ON							

Car Specific Dipswitch Settings

Manufacturer	Model	Start Year	End Year	Phone Button Support	CAN / Analogue	Dipswitch Setting							Outputs				
						1	2	3	4	5	6	7	Reverse	Speed	Park Brake		
Peugeot	108	2014		Y	Analogue	ON	ON	ON		ON		ON					
	206	1998	2002	N	Analogue		ON					ON					
	207	2006	2012	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	207	2006	2012	N	CAN		ON	ON		ON	ON	ON	YES	YES	YES	YES	
	208	2012		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	306	1998	2002	N	Analogue		ON					ON					
	307	2005	2008	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	307	2005	2008	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	308	2008		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	308	2008		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	3008	2009		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	407	2004	2010	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	4007	2007		Y	Analogue	ON			ON	ON		ON					
	4008	2014		Y	Analogue		ON	ON		ON		ON					
	5008	2009	2013	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	607	2004	2012	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	806	1996	2002	N	Analogue		ON					ON					
	807	2005	2014	N	CAN		ON			ON	ON	ON	YES	YES	YES	YES	
	Bipper	2008		Y	CAN		ON	ON	ON	ON	ON						
	Boxer	2006	2008	N	CAN		ON	ON	ON		ON	ON	YES	YES	YES	YES	
Boxer	2008	2014	N	CAN		ON	ON			ON	ON	YES	YES	YES	YES		
Boxer	2014		Y	CAN		ON	ON	ON	ON	ON		YES	YES	YES	YES		
Partner	2008		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES		
RCZ	2010		N	CAN		ON			ON	ON	ON	YES	YES	YES	YES		
Porsche	Cayenne	2002	2007	N	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
	Cayenne	2007	2010	N	CAN	ON	ON		ON	ON	ON	ON	YES	YES	YES	YES	
Proton	GEN-2	2004		N	Analogue	ON	ON	ON			ON	ON					
Renault	Clio	2005	2009	N	CAN				ON	ON	ON	ON	YES	YES	YES	YES	
	Clio	2009	2013	Y	CAN					ON	ON	ON	YES	YES	YES	YES	
	Fluence	2010		Y	CAN					ON	ON	ON	YES	YES	YES	YES	
	Laguna	2005	2007	N	CAN				ON	ON	ON	ON	YES	YES	YES	YES	
	Laguna	2008		Y	CAN					ON	ON	ON	YES	YES	YES	YES	
	Megane	2005	2008	N	CAN				ON	ON	ON	ON	YES	YES	YES	YES	
	Megane	2008	2012	Y	CAN					ON	ON	ON	YES	YES	YES	YES	
	Modus	2005	2012	N	CAN				ON	ON	ON	ON	YES	YES	YES	YES	
	Scala	2011		N	Analogue	ON		ON	ON			ON					
	Scenic	2005	2009	N	CAN				ON	ON	ON	ON	YES	YES	YES	YES	
	Scenic	2009		Y	CAN					ON	ON	ON	YES	YES	YES	YES	
	Trafic	2006		N	CAN				ON	ON	ON	ON	YES	YES	YES	YES	
	Trafic	2010	2013	Y	CAN					ON	ON	ON	YES	YES	YES	YES	
Twingo	2007	2009	N	CAN				ON	ON	ON	ON	YES	YES	YES	YES		
Wind	2010	2013	Y	CAN					ON	ON	ON	YES	YES	YES	YES		
Rover	25	2000	2005	N	Analogue						ON	ON					
	25	2000	2005	N	Analogue					ON	ON	ON					
	45	2000	2005	N	Analogue					ON	ON						
	45	2000	2005	N	Analogue					ON	ON	ON					
	75	2000	2004	N	Analogue						ON	ON					
	75	2000	2005	N	Analogue					ON	ON						
	75	2000	2005	N	Analogue					ON	ON	ON					
	ZR	2001	2005	N	Analogue						ON	ON					
	Z5	2001	2005	N	Analogue						ON	ON					
ZT	2001	2005	N	Analogue						ON	ON						
SAAB	95	1998	2002	N	Analogue	ON	ON	ON	ON		ON						
	93	1998	2002	N	Analogue	ON	ON	ON	ON		ON						
Scania	R 480	2004	2015	N	CAN	ON	ON		ON	ON	ON						
Skoda	Fabia	2007	2014	Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Fabia	2013		N	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Octavia	2004	2008	Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Octavia	2008	2013	N	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Rapid	2010		N	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Roomster	2008	2015	Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Superb	2008	2013	N	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Yeti	2010	2014	N	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
Yeti	2014		Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES		
SEAT	Altea	2004	2015	Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Alhambra	2015		Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Exeo	2009	2013	Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Ibiza	2008		Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Leon	2005	2014	Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	
	Toledo	2004		Y	CAN	ON	ON			ON	ON	ON	YES	YES	YES	YES	

Car Specific Dipswitch Settings

Manufacturer	Model	Start Year	End Year	Phone Button Support	CAN / Analogue	Dipswitch Setting							Outputs				
						1	2	3	4	5	6	7	Reverse	Speed	Park Brake		
Subaru	Forester	2007	2011	Y	Analogue	ON				ON	ON	ON					
	Forester	2012		Y	Analogue	ON				ON	ON	ON					
	Forester	2015		Y	Analogue		ON	ON	ON		ON	ON					
	Impreza	2007	2012	Y	Analogue	ON				ON	ON	ON					
	Impreza	2012	2015	Y	Analogue	ON				ON	ON	ON					
	Impreza	2015		Y	Analogue		ON	ON	ON		ON	ON					
	Outback	2012		Y	Analogue	ON				ON	ON	ON					
	XV	2012	2015	Y	Analogue	ON				ON	ON	ON					
XV	2015		Y	Analogue		ON	ON	ON		ON	ON						
SsangYong	Actyon	2006		N	Analogue				ON	ON	ON	ON					
	Actyon	2012		Y	Analogue				ON	ON	ON	ON					
	Korando	2010		Y	Analogue	ON				ON	ON	ON					
	Korando	2010		N	Analogue					ON	ON	ON					
	Korando Sport	2012		N	Analogue					ON	ON	ON					
	Korando Sport	2012		Y	Analogue				ON	ON	ON	ON					
	Rexton	2007	2012	N	Analogue					ON	ON	ON					
	Rexton	2007		Y	Analogue				ON	ON	ON	ON					
	Rexton W	2013		Y	Analogue				ON	ON	ON	ON					
	Rodius	2013		N	Analogue					ON	ON	ON					
	Rodius Turismo	2013		Y	Analogue					ON	ON	ON					
	Stavic	2013		Y	Analogue					ON	ON	ON					
Suzuki	Tivoli EX/ELX	2015		Y	Analogue					ON	ON	ON					
	Tivoli SE	2015		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Dzire	2008	2010	N	Analogue	ON				ON	ON	ON					
	Ertiga	2012	2015	Y	Analogue	ON				ON	ON	ON					
	Fun	2002	2010	N	Analogue				ON	ON	ON	ON					
	Grand Nomade		2009	N	Analogue	ON				ON	ON	ON					
	Grand Vitara	2005	2011	N	Analogue	ON				ON	ON	ON					
	Grand Vitara	2011	2015	Y	Analogue	ON				ON	ON	ON					
	Ritz	2009		N	Analogue	ON				ON	ON	ON					
	Splash	2009		N	Analogue	ON				ON	ON	ON					
	Swift	2006	2011	N	Analogue	ON				ON	ON	ON					
	Swift	2011		Y	Analogue	ON				ON	ON	ON					
SX4	2006		N	Analogue	ON				ON	ON	ON						
SX4 S Cross	2013		Y	Analogue	ON				ON	ON	ON						
Vitara	2015		Y	Analogue	ON				ON	ON	ON						
Tata	Indigo	2006		Y	Analogue		ON			ON	ON	ON					
	Manza	2012		Y	Analogue				ON	ON	ON	ON					
	Vista	2012		Y	Analogue		ON			ON	ON	ON					
Toyota	4Runner	2002		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Avanza	2003		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Avensis	2001	2011	Y	Analogue	ON	ON	ON		ON	ON	ON					
	Avensis	2011		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Aygo	2014		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Corolla	2001	2011	Y	Analogue	ON	ON	ON		ON	ON	ON					
	Corolla	2011		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Estima	2006		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Fortuner	2005		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Hilux	2012		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Innova	2006		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Landcruiser	2007		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Matrix	2003		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Prado	2007		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Previa	2006		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Rav4	2001		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Rush	2006		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Verso	2011		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Vios	2006		Y	Analogue	ON	ON	ON		ON	ON	ON					
	Yaris	2001		Y	Analogue	ON	ON	ON		ON	ON	ON					
Volvo	S60	2004	2004	N	CAN	ON	ON	ON		ON	ON		YES		YES		
	V70	2000	2004	N	CAN	ON		ON	ON		ON		YES		YES		
VW	Amarok	2010		Y	CAN	ON	ON		ON	ON	ON		YES	YES	YES		
	Beetle	2015		Y	CAN	ON	ON		ON	ON	ON		YES	YES	YES		
	Caddy	2015		Y	CAN	ON	ON		ON	ON	ON		YES	YES	YES		
	Crafter	2006		Y	CAN	ON		ON	ON	ON	ON		YES	YES	YES		
	Crafter	2006		Y	CAN	ON		ON	ON	ON	ON		YES	YES	YES		
	Crafter	2012	2014	Y	CAN	ON		ON	ON	ON	ON						
	Crafter	2014		Y	CAN	ON		ON	ON	ON	ON		YES	YES	YES		
	EOS	2006	2015	Y	CAN	ON	ON		ON	ON	ON		ON	YES	YES	YES	
	Fusca	2005	2011	Y	CAN	ON	ON		ON	ON	ON		ON	YES	YES	YES	
	Gol	2012		Y	CAN	ON			ON		ON		ON	YES	YES	YES	
	Golf	2003	2013	Y	CAN	ON	ON		ON	ON	ON		ON	YES	YES	YES	

Car Specific Dipswitch Settings


Manufacturer	Model	Start Year	End Year	Phone Button Support	CAN / Analogue	Dipswitch Setting							Outputs		
						1	2	3	4	5	6	7	Reverse	Speed	Park Brake
VW	Jetta	2005	2015	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Jetta	2015		Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Magotan	2005	2011	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Multivan	2003	2008	N	CAN	ON	ON				ON	ON	YES	YES	YES
	Passat	2005	2015	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Polo	2005	2014	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Sagitar	2005	2011	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Scirocco	2008	2015	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Sharan	2015		Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Suran	2009		Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	T-6	2015		Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Tiguan	2007	2015	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Tiguan	2015		Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Toureg	2003	2010	N	CAN	ON	ON				ON	ON	YES	YES	YES
	Touran	2003	2015	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Transporter	2003	2015	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Vento	2005	2011	Y	CAN	ON	ON		ON	ON		ON	YES	YES	YES
	Vauxhall/Opel	Agila	2009	2015	N	Analogue						ON	ON		
Antara		2006	2010	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES
Antara		2010		N	CAN	ON	ON				ON		YES	YES	YES
Astra		1998	2004	N	Analogue			ON			ON	ON			
Astra		2004	2010	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES
Astra Classic		2004	2009	N	Analogue			ON			ON	ON			
Corsa		2000	2006	N	Analogue			ON			ON	ON			
Corsa		2005	2009	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES
Meriva		2003	2007	N	Analogue			ON			ON	ON			
Meriva		2007	2010	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES
Omega		2000	2004	N	Analogue			ON			ON	ON			
Signum		2005	2008	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES
Tigra		2005	2009	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES
Vectra		1998	2004	N	Analogue			ON			ON	ON			
Vectra		2004	2008	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES
Vivaro		2002	2007	N	Analogue			ON			ON	ON			
Vivaro		2011	2013	Y	CAN					ON	ON	ON	YES	YES	YES
Zafira		1999	2005	N	Analogue			ON			ON	ON			
Zafira	2005	2014	Y	CAN			ON	ON	ON	ON	ON	YES	YES	YES	

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side



Mini-ISO Vehicles




147/GT CAN-Bus	
Interface Wire	Pin Number
Analogue 1	20
Analogue 2	33
Analogue Ground	27
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4

147/156/GT Analogue	
Interface Wire	Pin Number
Analogue 1	20
Analogue 2	33
Analogue Ground	27
Batt 12V	2
Ground	4

159/Brera/Giulietta/Mito	
Interface Wire	Pin Number
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4

Giulietta/Mito/4C OEM Specific




Giulietta/Mito/4C	
Interface Wire	Pin Number
CAN High	2
CAN Low	12
Batt 12V	44
Ground	43

Car Specific Wiring Information




Mini-ISO Vehicles



CAN-Bus Vehicles	
Interface Wire	Pin Number
CAN High	32
CAN Low	27
Batt 12V	2
Ground	4

Audi CAN-Bus Quadlock




Audi CAN-Bus Quadlock	
Interface Wire	Pin Number
CAN High	9
CAN Low	10
Batt 12V	15
Ground	12



17 Way Round Pin i-Bus Vehicles

*Note that the Batt 12V wire should be connected directly to the vehicle battery as the vehicle connector does not have a permanent 12V feed.




17 Way i-Bus Vehicles	
Interface Wire	Pin Number
Analogue 2	14
Batt 12V	11
Ground	10

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side

BMW Continued...


40 Way Flat Pin Quadlock i-Bus Vehicles



*Note that BMW i-Bus vehicles require a 4k7 resistor putting between the Batt 12V wire and the i-Bus wire (Analogue 2).

40 Way i-Bus Vehicles	
Interface Wire	Pin Number
Analogue 2	9
Batt 12V	15
Ground	12


Quadlock CAN-Bus Vehicles



Quadlock CAN-Bus Vehicles	
Interface Wire	Pin Number
CAN High	11
CAN Low	9
Batt 12V	To Battery*
Ground	12



16 Way Kenwood Connector




Chery Tiggo	
Interface Wire	Pin Number
Analogue 1	2
Analogue Ground	5
Batt 12V	8
Ground	16

Car Specific Wiring Information



Mini-ISO Connector




Chrysler Delta	
Interface Wire	Pin Number
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4




CITROËN

Quadlock CAN-Bus Vehicles



Quadlock CAN-Bus Vehicles	
Interface Wire	Pin Number
CAN High	10
CAN Low	13
Batt 12V	12
Ground	16

Jumper OEM Specific




Jumper CAN-Bus 2014>	
Interface Wire	Pin Number
CAN High	2
CAN Low	12
Batt 12V	44
Ground	43

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side



Citroën Continued...

Mini-ISO Connector



C1 OEM Specific



Relay/Jumper 2006-2008 Relay/Jumper 2008-2013 Evasion/Synergie 2006-2002 Dispatch 2007	
Interface Wire	Pin Number
Analogue 1	20
Analogue 2	33
Analogue Ground	27
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4



C1	
Interface Wire	Pin Number
Analogue 1	A20
Analogue 2	A19
Analogue Ground	A21
Batt 12V	B4
Ground	B7



Fujitsu Ten Specific Connector




Aveo, Captiva	
Interface Wire	Pin Number
Analogue 2	B12
Analogue Ground	A12
Batt 12V	A1
Ground	A8

Car Specific Wiring Information


Chevrolet Continued...

White S10 Connector




S10	
Interface Wire	Pin Number
Analogue 1	5
Analogue Ground	13
Batt 12V	14
Ground	10

White Spark Connector



Spark 2010-2012	
Interface Wire	Pin Number
Analogue 1	8
Analogue Ground	5
Batt 12V	15
Ground	6

Spark/Sonic OEM Specific




Spark, Sonic	
Interface Wire	Pin Number
Analogue 2	19
Analogue Ground	5
Batt 12V	44
Ground	38

Car Specific Wiring Information


All connectors are shown from the terminal side and NOT the wire side



Fujitsu Ten Specific Connector



A




B

Winstorm	
Interface Wire	Pin Number
Analogue 2	B12
Analogue Ground	A12
Batt 12V	A1
Ground	A8




OEM Specific



DAF CF/XF No OEM Radio	
Interface Wire	Pin Number
CAN High	21
CAN Low	20
Batt 12V	25
Ground	1

40 Way MOST Quadlock CAN-Bus Vehicles




DAF CF/XF Quadlock	
Interface Wire	Pin Number
CAN High	9
CAN Low	10
Batt 12V	15
Ground	12

Car Specific Wiring Information



DODGE


OEM Specific Connector



RAM Promaster	
Interface Wire	Pin Number
CAN High	2
CAN Low	12
Batt 12V	44
Ground	43




8 Way ISO Connector



Bravo, Ritmo, Stilo	
Interface Wire	Pin Number
Analogue 1	5
Analogue 2	1
Analogue Ground	4
Batt 12V	8
Ground	4

Sedici OEM Connector




Sedici 2006-2014	
Interface Wire	Pin Number
Analogue 1	8
Analogue 2	19
Analogue Ground	20
Batt 12V	1
Ground	11

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side

Fiat Continued...

Mini-ISO Connector



500, Qubo, Punto, Ducato, Fiorino, Idea, Doblo	
Interface Wire	Pin Number
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4


Ducato 2008 - 2014	
Interface Wire	Pin Number
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4

Ducato <2008	
Interface Wire	Pin Number
Analogue 1	20
Analogue 2	33
Analogue Ground	27
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4

Ducato 07-11, Multipla 04, Panda 04-07	
Interface Wire	Pin Number
Analogue 1	17
Analogue 2	30
Analogue Ground	24
Batt 12V	8
Ground	4

Panda	
Interface Wire	Pin Number
CAN High	5
CAN Low	6
Analogue 1	20
Analogue 2	33
Analogue Ground	27
Batt 12V	2
Ground	4

OEM Specific Connector




500L, Ducato 2014>	
Interface Wire	Pin Number
CAN High	2
CAN Low	12
Batt 12V	44
Ground	43

Car Specific Wiring Information




24 Way New Connector (Vehicles with Display)




B-Max, Kuga, Fiesta, C-Max, Focus, Transit-Custom, Transit-Connect Escape, Ecosport, Taurus, Ranger (inc. S.American Models)	
Interface Wire	Pin Number
CAN High	A4
CAN Low	A5
Analogue 1	A7
Analogue Ground	A10
Batt 12V	B1
Ground	B13

Quadlock CAN-Bus Vehicles



Quadlock CAN-Bus Vehicles	
Interface Wire	Pin Number
CAN High	9
CAN Low	10
Analogue 1	22
Analogue Ground	24
Batt 12V	15
Ground	12

24 Way Ford Connector




Everest, Transit-Custom, Transit, Ranger 15+	
Interface Wire	Pin Number
CAN High	14
CAN Low	15
Batt 12V	1
Ground	13

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side


Ford Continued...

Fiesta/F150/Fusion





Fiesta 02-05, F150 04-08, Fusion 02-05 Analogue	
Interface Wire	Pin Number
Analogue 1	18
Analogue Ground	19
Batt 12V	1
Ground	13

Fiesta/Transit (Vehicles without Display)



Fiesta, Transit 2013>	
Interface Wire	Pin Number
Analogue 1	9
Analogue Ground	20
Batt 12V	1
Ground	13

Old Style Analogue Vehicles




Old Style Analogue	
Interface Wire	Pin Number
Analogue 1	B5
Analogue Ground	B6
Batt 12V	A3
Ground	A8

Car Specific Wiring Information



Great Wall

8 Way ISO Connector




H6	
Interface Wire	Pin Number
Analogue 1	6
Analogue 2	1
Analogue Ground	5
Batt 12V	8
Ground	4

Steed, Wingle	
Interface Wire	Pin Number
Analogue 2	1
Analogue Ground	5
Batt 12V	8
Ground	4



Street Glide OEM Connector



Street Glide	
Interface Wire	Pin Number
CAN High	1
CAN Low	11
Batt 12V	46
Ground	45


Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side



HONDA

Analogue Vehicles




A



B

Analogue	
Interface Wire	Pin Number
Analogue 1	B4
Analogue Ground	B5
Batt 12V	A10
Ground	A1

Civic CAN-Bus 2012>




A




B

Civic CAN-Bus 2012>	
Interface Wire	Pin Number
CAN High	B13
CAN Low	B3
Batt 12V	A13
Ground	A1

City/Fit/HR-V/Jazz OEM Specific



A




B

City, Fit, HR-V, Jazz 14>	
Interface Wire	Pin Number
Analogue 1	A21
Analogue 2	B12
Analogue Ground	A8
Batt 12V	A13
Ground	A1

Car Specific Wiring Information

Honda Continued...

CR-V/S2000/Jazz OEM Specific




CR-V 05-07, S2000 2001>	
Interface Wire	Pin Number
Analogue 1	8
Analogue Ground	7
Batt 12V	1
Ground	11

Jazz 05-08	
Interface Wire	Pin Number
Analogue 1	8
Analogue Ground	20
Batt 12V	1
Ground	11




HYUNDAI

Mini-ISO Connector



Santa Fe 2006-2010



Mini-ISO Vehicles	
Interface Wire	Pin Number
Analogue 2	19
Analogue Ground	20
Batt 12V	8
Ground	4


Santa Fe 2006-2010	
Interface Wire	Pin Number
Analogue 2	6
Analogue Ground	18
Batt 12V	12
Ground	24

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side

Hyundai Continued...


Hyundai White Connector



Hyundai White Connector	
Interface Wire	Pin Number
Analogue 2	B4
Analogue Ground	B17
Batt 12V	B12
Ground	B24

ISUZU


D-Max Connector



D-Max 12>, MU-X 14>, Chevrolet Colorado 12-14	
Interface Wire	Pin Number
Analogue 1	5
Analogue Ground	13
Batt 12V	14
Ground	10

IVECO

Daily Connector




Daily	
Interface Wire	Pin Number
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4

Car Specific Wiring Information



8 Way ISO Connector




J3 2013>	
Interface Wire	Pin Number
Analogue 1	1
Analogue Ground	6
Batt 12V	8
Ground	4




JAGUAR

XJ8 Connector



XJ8 1998-2003	
Interface Wire	Pin Number
Analogue 2	2
Analogue Ground	To vehicle chassis
Batt 12V	10
Ground	To vehicle chassis

S/X Type Connector





S/X Type	
Interface Wire	Pin Number
Analogue 1	13
Analogue Ground	To vehicle chassis
Batt 12V	20
Ground	10

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side

Jaguar Continued...


S Type Connector



S Type 99-02	
Interface Wire	Pin Number
Analogue 1	B5
Analogue Ground	B6
Batt 12V	A3
Ground	A8




Cee'd 2007-2009



Cee'd 2007-2009	
Interface Wire	Pin Number
Analogue 2	19
Analogue Ground	26
Batt 12V	8
Ground	4

Mini-ISO Vehicles




Mini-ISO Vehicles	
Interface Wire	Pin Number
Analogue 2	19
Analogue Ground	20
Batt 12V	8
Ground	4


Car Specific Wiring Information

Kia Continued...

Kia White Connector



A




B

Kia White Connector	
Interface Wire	Pin Number
Analogue 2	B4
Analogue Ground	B17
Batt 12V	B12
Ground	B24

Sorento/Carnival/Sedona 15>	
Interface Wire	Pin Number
CAN High	B1
CAN Low	B13
Batt 12V	B12
Ground	B24



Delta Connector




Delta 09>	
Interface Wire	Pin Number
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side




17 Way BMW Connector




Land Rover Discovery/ Freelander with 17 way BMW Connector	
Interface Wire	Pin Number
Analogue 1	16
Analogue Ground	10
Batt 12V	11
Ground	10

Land Rover Discovery Connector



Land Rover Discovery 2003>	
Interface Wire	Pin Number
Analogue 1	1
Analogue Ground	To vehicle chassis
Batt 12V	2
Ground	4

CAN-Bus Connector




Freelander, Discovery, Range Rover Sport CAN-Bus	
Interface Wire	Pin Number
CAN High	2
CAN Low	1
Analogue 1	13
Analogue Ground	10
Batt 12V	20
Ground	10

Car Specific Wiring Information



Lifan OEM Connector




Lifan Motors 620/720	
Interface Wire	Pin Number
Analogue 1	5
Analogue 2	1
Analogue Ground	4
Batt 12V	8
Ground	4



Mahindra

Scorpio Connector




Scorpio	
Interface Wire	Pin Number
Analogue 1	A1
Analogue Ground	A6
Batt 12V	A8
Ground	A4



mazda

2 2007>




2 2007>	
Interface Wire	Pin Number
Analogue 1	12
Analogue Ground	13
Batt 12V	14
Ground	24

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side


Mazda Continued...

6 2007-2009




6 2007-2009	
Interface Wire	Pin Number
CAN High	20
CAN Low	21
Analogue 1	12
Analogue Ground	13
Batt 12V	14
Ground	24

3 2004-2008



3 2004-2008	
Interface Wire	Pin Number
Analogue 1	12
Analogue Ground	13
Batt 12V	14
Ground	24

CX-7, CX-9




CX-7, CX-9	
Interface Wire	Pin Number
Analogue 1	12
Analogue Ground	13
Batt 12V	14
Ground	24

Car Specific Wiring Information




Mercedes-Benz

8 Way ISO CAN-Bus Vehicles



8 Way ISO CAN-Bus	
Interface Wire	Pin Number
CAN High	3
CAN Low	8
Batt 12V	2
Ground	4

Quadlock CAN-Bus Vehicles



A/B/C Quadlock CAN Bus Vehicles	
Interface Wire	Pin Number
CAN High	11
CAN Low	9
Batt 12V	15
Ground	12


Vito (W447 with Audio 15)	
Interface Wire	Pin Number
CAN High	11
CAN Low	9
Batt 12V	15
Ground	12

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side


Mercedes Continued...

E Class/SLK Quadlock




E Class/SLK Quadlock	
Interface Wire	Pin Number
CAN High	17
CAN Low	18
Batt 12V	16
Ground	15

Mini-ISO CAN-Bus Vehicles



Mini-ISO CAN-Bus	
Interface Wire	Pin Number
CAN High	17
CAN Low	30
Batt 12V	2
Ground	4

10 Way ISO CAN-Bus Vehicles




10 Way ISO CAN-Bus	
Interface Wire	Pin Number
CAN High	1
CAN Low	6
Batt 12V	24
Ground	26

Car Specific Wiring Information





Outlander 2013>





Outlander 2013>	
Interface Wire	Pin Number
CAN High	8
CAN Low	18
Analogue 1	9
Analogue Ground	11
Batt 12V	1
Ground	11

ASX, Lancer, Outlander 2010>
Pajero, Shogun 2013>



ASX, Lancer, Outlander 2010>, Pajero, Shogun 2013>	
Interface Wire	Pin Number
Analogue 1	A9
Analogue Ground	To vehicle chassis
Batt 12V	A1
Ground	To vehicle Chassis


Outlander/Lancer 2007-2010



Lancer, Outlander 2007-2010	
Interface Wire	Pin Number
Analogue 1	A9
Analogue Ground	To vehicle chassis
Batt 12V	A1
Ground	To vehicle Chassis

Car Specific Wiring Information


All connectors are shown from the terminal side and NOT the wire side




All Models

All Models	
Interface Wire	Pin Number
Analogue 1	8
Analogue 2	17
Analogue Ground	7
Batt 12V	1
Ground	To vehicle chassis

8 & 16 Way Connector




A




B

Almera/Primera/Terrano X-Trail	
Interface Wire	Pin Number
Analogue 1	B4
Analogue 2	B5
Analogue Ground	B3
Batt 12V	A8
Ground	A9


6 & 10 Way Connector



A



B



C


350Z 03>, Navara 06>, X-Trail 01>	
Interface Wire	Pin Number
Analogue 1	B13
Analogue 2	B3
Analogue Ground	B5
Batt 12V	A4
Ground	To vehicle chassis

Car Specific Wiring Information




PEUGEOT

Quadlock CAN-Bus Vehicles




Quadlock CAN-Bus Vehicles	
Interface Wire	Pin Number
CAN High	10
CAN Low	13
Batt 12V	12
Ground	16

Mini-ISO Analogue Vehicles




206/306 98-02, 806 96-02	
Interface Wire	Pin Number
Analogue 1	17
Analogue 2	30
Analogue Ground	24
Batt 12V	8
Ground	4

108 OEM Connector



A




B

108	
Interface Wire	Pin Number
Analogue 1	A20
Analogue 2	A19
Analogue Ground	A21
Batt 12V	B4
Ground	B7


Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side

Peugeot Continued... Boxer OEM Connector



Boxer 2014>	
Interface Wire	Pin Number
CAN High	2
CAN Low	12
Batt 12V	44
Ground	43




Boxer 06-08/08-14	
Interface Wire	Pin Number
Analogue 1	20
Analogue 2	33
Analogue Ground	27
CAN High	5
CAN Low	6
Batt 12V	2
Ground	4



PORSCHE

Cayenne Mini ISO




Cayenne 2002-2007 Mini-ISO	
Interface Wire	Pin Number
CAN High	30
CAN Low	17
Batt 12V	2
Ground	4

Car Specific Wiring Information

Porsche Continued...


Cayenne Quadlock



Cayenne 2002-2007 Quadlock	
Interface Wire	Pin Number
CAN High	11
CAN Low	9
Batt 12V	12
Ground	15




GEN-2 Mini ISO



GEN-2	
Interface Wire	Pin Number
Analogue 1	20
Analogue 2	33
Analogue Ground	27
Batt 12V	2
Ground	4



Mini-ISO with 'Update List' OEM head unit




Mini-ISO with 'Update List' OEM head unit	
Interface Wire	Pin Number
CAN High	B6
CAN Low	B2
Batt 12V	A2
Ground	A4

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side


Renault Continued...

CAN-Bus Quadlock




Renault CAN-Bus 2009> with Quadlock Connector	
Interface Wire	Pin Number
CAN High	13
CAN Low	9
Batt 12V	15
Ground	12

CAN-Bus Mini-ISO



Renault CAN-Bus 2009> with Mini-ISO Connector	
Interface Wire	Pin Number
CAN High	17
CAN Low	30
Batt 12V	2
Ground	4

Scala OEM Connector




Scala	
Interface Wire	Pin Number
Analogue 1	8
Analogue 2	17
Analogue Ground	7
Batt 12V	1
Ground	To vehicle chassis

Car Specific Wiring Information




Rover 75 with Highline OEM head unit




Rover 75 with Highline	
Interface Wire	Pin Number
Analogue 1	1
Analogue Ground	To vehicle chassis
Batt 12V	2
Ground	4

17 Way BMW Connector



17 way BMW Connector	
Interface Wire	Pin Number
Analogue 1	16
Analogue Ground	N/R
Batt 12V	11
Ground	10

25/45/75 Mini-ISO Vehicles



25/45/75 Mini ISO	
Interface Wire	Pin Number
Analogue 2	20
Analogue Ground	27
Batt 12V	8
Ground	4


Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side



Saab 9.3/9.5 1998-2005

*Connect analogue 2 to green wire in 2 pin connector located under steering column.
The analogue 2 wire may need to be extended.




Saab 9.3/9.5 98-05	
Interface Wire	Pin Number
Analogue 2	See diagram*
Batt 12V	8
Ground	4



SCANIA

Scania R Series 8 Way ISO




Scania R Series	
Interface Wire	Pin Number
CAN High	5
CAN Low	1
Batt 12V	2
Ground	4

ŠKODA



Skoda CAN-Bus Quadlock




Skoda CAN-Bus Quadlock	
Interface Wire	Pin Number
CAN High	9
CAN Low	10
Batt 12V	15
Ground	12

Car Specific Wiring Information




SEAT

Seat CAN-Bus Quadlock




Seat CAN-Bus Quadlock	
Interface Wire	Pin Number
CAN High	9
CAN Low	10
Batt 12V	15
Ground	12

Seat Exeo Mini ISO



Exeo Symphony Mini-ISO	
Interface Wire	Pin Number
CAN High	30
CAN Low	17
Batt 12V	2
Ground	4

Seat MIB-PQ 52 Way Quadlock



Seat Alhambra (MIB-PQ)	
Interface Wire	Pin Number
CAN High	22
CAN Low	28
Batt 12V	16
Ground	15


Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side




SUBARU

Forester/Impreza
2007-2012




Forester/Impreza 2007-2012	
Interface Wire	Pin Number
Analogue 1	17
Analogue Ground	7
Batt 12V	1
Ground	11

Impreza, Forester,
Outback, XV 2012>




Impreza, Forester, Outback, XV 2012>	
Interface Wire	Pin Number
Analogue 1	17
Analogue 2	8
Analogue Ground	7
Batt 12V	1
Ground	11


Impreza, Forester,
XV 2015>



A



B




C

Impreza, Forester, XV 2015>	
Interface Wire	Pin Number
Analogue 1	A21
Analogue 2	A22
Analogue Ground	B4
Batt 12V	B4
Ground	B7

Car Specific Wiring Information




Actyon/Rexton/Korando Sport/
Rodius Connector



Actyon 2006>, Rexton 2007>, Korando Sport 2012, Rodius 2013>	
Interface Wire	Pin Number
Analogue 1	16
Analogue Ground	14
Batt 12V	5
Ground	14

Tivoli EX/ELX/SE OEM Connector



Tivoli EX / ELX	
Interface Wire	Pin Number
Analogue 1	B17
Analogue Ground	B4
Batt 12V	B12
Ground	B24


Tivoli SE	
Interface Wire	Pin Number
Analogue 1	A9
Analogue Ground	A18
Batt 12V	B12
Ground	B24

Car Specific Wiring Information

All connectors are shown from the terminal side and NOT the wire side

Ssangyong Continued...

All other Ssangyong models




All other Ssangyong models	
Interface Wire	Pin Number
Analogue 2	16
Analogue Ground	13
Batt 12V	5
Ground	14



SUZUKI

All Suzuki models




Suzuki all models	
Interface Wire	Pin Number
Analogue 1	19
Analogue 2	8
Analogue Ground	20
Batt 12V	1
Ground	11



TATA

All Tata models






Tata Vista, Manza, Indigo	
Interface Wire	Pin Number
Analogue 2	20
Analogue Ground	27
Batt 12V	2
Ground	4

Car Specific Wiring Information






TOYOTA

Toyota <2011



Toyota <2011	
Interface Wire	Pin Number
Analogue 1	A8
Analogue 2	A7
Analogue Ground	A6
Batt 12V	B4
Ground	B7

Toyota 2011>




Toyota 2011>	
Interface Wire	Pin Number
Analogue 1	A21
Analogue 2	A22
Analogue Ground	B4
Batt 12V	B4
Ground	B7

Car Specific Wiring Information


All connectors are shown from the terminal side and NOT the wire side

Toyota Continued...

Toyota Aygo 2014>



A




B

Aygo 2014>	
Interface Wire	Pin Number
Analogue 1	A20
Analogue 2	A19
Analogue Ground	A21
Batt 12V	B4
Ground	B7




All Volvo models

Green



A

Grey




B

S60, V70	
Interface Wire	Pin Number
CAN High	A12
CAN Low	A11
Batt 12V	A6
Ground	A7




VW CAN-Bus All Models
40 Way Quadlock



VW CAN-Bus Quadlock	
Interface Wire	Pin Number
CAN High	9
CAN Low	10
Batt 12V	15
Ground	12


Car Specific Wiring Information

VW CAN-Bus MIB-PQ 52 Way Quadlock



52 Way Quadlock (MIB-PQ)	
Interface Wire	Pin Number
CAN High	22
CAN Low	28
Batt 12V	16
Ground	15

VW Crafter 2006> Quadlock



Crafter 2006>	
Interface Wire	Pin Number
CAN High	11
CAN Low	9
Batt 12V	15
Ground	12

Car Specific Wiring Information


All connectors are shown from the terminal side and NOT the wire side



VAUXHALL




Vauxhall/Opel Analogue




Vauxhall/Opel Analogue	
Interface Wire	Pin Number
Analogue 1	1
Analogue Ground	4
Batt 12V	8
Ground	4

Vauxhall/Opel CAN-Bus



Vauxhall/Opel CAN-Bus	
Interface Wire	Pin Number
CAN High	9
CAN Low	10
Batt 12V	15
Ground	12

Vivaro Mini ISO



Vivaro 2011>	
Interface Wire	Pin Number
CAN High	17
CAN Low	30
Batt 12V	2
Ground	4