

Make	CAR MODEL	YEAR					DRIVER			PASSENGER		
		年	月	→	年	月	SIZE	SIZE-mm	ADAPTER	SIZE	SIZE-mm	ADAPTER
BEDFORD	Rascal	1986	06	→	1990	06	16"	400mm	E3	14"	350mm	E3
BELLIER	Electrique	2000	01	→			14"	350mm	E3			
BELLIER	Millenium	2000	01	→			18"	450mm	E3	14"	350mm	E3
BENTLEY	T Series	1974	01	→	1980	12	14"	350mm	E3	14"	350mm	E3
CHEVROLET	Matiz	2005	02	→	2010	12	22"	550mm	E3	14"	350mm	E3
CHEVROLET	Spark (KL1K, M200)	2005	02	→	2010	12	22"	550mm	E3	14"	350mm	E3
CITROEN	LN/LNA	1976	11	→	1981	12	14"	350mm	E3	14"	350mm	E3
DAIHATSU	Bus-Wide 55	1980	04	→	1983	04	14"	350mm	E3	14"	350mm	E3
DAIHATSU	Charade (NSP90)	2011	03	→			24"	600mm	E3	14"	350mm	E3
DAIHATSU	Sparcar Box	1983	09	→	1986	05	14"	350mm	E3	14"	350mm	E3
DAIHATSU	Sparcar Bus	1983	09	→	1986	05	14"	350mm	E3	14"	350mm	E3
DAIHATSU	YRV (M2)	2000	08	→	2005	07	21"	525mm	E3	14"	350mm	E3
DAIMLER	Sovereign/Double Six XJ series	1980	01	→	1983	09	14"	350mm	E3	14"	350mm	E3
FIAT	500	2007	07	→			24"	600mm	3H-8	14"	350mm	3H-8
FIAT	500 C	2009	07	→			24"	600mm	3H-8	14"	350mm	3H-8
FIAT	500 EV (3C3)	2012	03	→			24"	600mm	E3	14"	350mm	E3
FIAT	500 L Living	2013	09	→			26"	650mm	3H-8	14"	350mm	3H-8
FIAT	Sedici SUV	2006	04	→			26"	650mm	E3	14"	350mm	E3
FORD	Ka II (08)	2008	09	→	2010	10	24"	600mm	E3	14"	350mm	E3
FORD	Ka II (08)	2010	11	→			24"	600mm	3H-8	14"	350mm	3H-8
GAZ	Volga 24	1970		→	1986		14"	350mm	E3	14"	350mm	E3
GAZ	Volga 2402	1972		→	1987		14"	350mm	E3	14"	350mm	E3
GAZ	Volga 31013	1982		→	1996		14"	350mm	E3	14"	350mm	E3
HONDA	Civic 7	2001	09	→	2006	12	24"	600mm	E3	14"	350mm	E3
HONDA	Jazz (GE)	2008	11	→			26"	650mm	E3	14"	350mm	E3
HONDA	Stream (RN)	2000	10	→	2006	07	24"	600mm	E3	14"	350mm	E3
HYUNDAI	Elantra (MD)	2011	02	→			26"	650mm	E3	14"	350mm	E3
HYUNDAI	Getz (TB)	2002	09	→	2009	06	22"	550mm	E3	14"	350mm	E3

HYUNDAI	i-30 (GD)	2011	12	→			26"	650mm	E3	14"	350mm	E3
HYUNDAI	i-30 Coupe (GD)	2013	02	→			26"	650mm	E3	14"	350mm	E3
HYUNDAI	i-30 CW Combi/Estate	2012	03	→			26"	650mm	E3	14"	350mm	E3
HYUNDAI	Sante Fé (DM)	2012	06	→			26"	650mm	E3	14"	350mm	E3
JAGUAR	XJ	2008	01	→	1983	09	14"	350mm	E3	14"	350mm	E3
KIA	Cee'd SW	2012	09	→			26"	650mm	E3	14"	350mm	E3
KIA	Cee'd/Pro Cee'd (JD)	2012	05	→			26"	650mm	E3	14"	350mm	E3
KIA	Pro Cee'd (JD)	2013	01	→			26"	650mm	E3	14"	350mm	E3
KIA	Retona (CE)	1998	04	→	2000	12	14"	350mm	E3	14"	350mm	E3
KIA	Venga (YN)	2009	12	→			26"	650mm	3H-8	14"	350mm	3H-8
MAZDA	2	2007	10	→			24"	600mm	E3	14"	350mm	E3
MAZDA	B-Serie (PE) Pickup	1977	02	→	1982	01	14"	350mm	E3	14"	350mm	E3
MAZDA	E 1600	1980	08	→	1984	06/84	14"	350mm	E3	14"	350mm	E3
MG	MGB Convertible	1972	01	→	1980	12	14"	350mm	E3	14"	350mm	E3
MG	MGB GT	1972	01	→	1980	11	14"	350mm	E3	14"	350mm	E3
MITSUBIAHI	Colt VI (CZ)	2004	09	→	2006	02	24"	600mm	E3	14"	350mm	E3
MITSUBIAHI	Colt VII (CZ)	2008	09	→			24"	600mm	E3	14"	350mm	E3
MITSUBIAHI	L1000	1978	01	→			14"	350mm	E3	14"	350mm	E3
MITSUBIAHI	Mirage (A0)	2012	11	→			22"	550mm	E3	14"	350mm	E3
MITSUBIAHI	Space Star (AO)	2012	11	→			22"	550mm	E3	14"	350mm	E3
NISSAN	Juke (F15)	2010	07	→			23"	575mm	E3	14"	350mm	E3
NISSAN	Micra (K13K)	2010	07	→			21"	525mm	E3	14"	350mm	E3
NISSAN	Note (E11, E11E) MPV	2005	01	→	2013	09	24"	600mm	E3	14"	350mm	E3
NISSAN	Pixo Hatchback(UA0)	2009	03	→			22"	550mm	E3	14"	350mm	E3
NISSAN	Tiida/Versa Hatchback (C11X)	2007	03	→			24"	600mm	E3	14"	350mm	E3
NISSAN	Tiida/Versa Saloon (SC11X)	2007	02	→			24"	600mm	E3	14"	350mm	E3
PEUGEOT	104	1972	10	→	1981	08	14"	350mm	E3	14"	350mm	E3
PEUGEOT	104 Coupe	1973	09	→	1981	08	14"	350mm	E3	14"	350mm	E3
RELIANT	Rialto	1982	01	→	1986	12	14"	350mm	E3	14"	350mm	E3
RELIANT	Scimitar GTC	1966	01	→	1977	12	14"	350mm	E3	14"	350mm	E3
RELIANT	Scimitar GTE	1968	01	→	1977	12	14"	350mm	E3	14"	350mm	E3

RELIANT	Scimitar SS1 Roadster	1985	01	→	1986	12	14"	350mm	E3	14"	350mm	E3
RENAULT	5	1978	01	→	1985	12	14"	350mm	E3	14"	350mm	E3
RENAULT	5 Box	1978	01	→	1985	12	14"	350mm	E3	14"	350mm	E3
RENAULT	ZOE (BF)	2013	01	→			24"	600mm	3H-8	14"	350mm	3H-8
ROLLS -ROYCE	Corniche	1972	01	→	1982	01	14"	350mm	E3	14"	350mm	E3
ROLLS -ROYCE	Silver Shadow	1965		→	1981	01	14"	350mm	E3	14"	350mm	E3
SUBARU	R1	2005	01	→			22"	550mm	E3	14"	350mm	E3
SUBARU	R2	2003		→			22"	550mm	E3	14"	350mm	E3
SUZUKI	Alto	2009	01	→			22"	550mm	E3	14"	350mm	E3
SUZUKI	Alto (SS80)	1982	06	→	1985	12	14"	350mm	E3	14"	350mm	E3
SUZUKI	Super Carry Bus (ED)	1985	10	→	1999	03	15"	375mm	E3	14"	350mm	E3
SUZUKI	SX4 Cross	2013	08	→			26"	650mm	E3	14"	350mm	E3
SUZUKI	SX4 Hatchback	2006	05	→			26"	650mm	E3	14"	350mm	E3
SUZUKI	SX4 S-Cross	2013	09	→			26"	650mm	E3	14"	350mm	E3
SUZUKI	SX4 Sedan	2007	07	→			26"	650mm	E3	14"	350mm	E3
SUZUKI	SX4 SUV	2006	06	→			26"	650mm	E3	14"	350mm	E3
SUZUKI	U 80	1980	01	→	1984	01	14"	350mm	E3	14"	350mm	E3
TALBOT	Rancho	1981	01	→	1984	07	14"	350mm	E3	14"	350mm	E3
TATA (TELCO)	Indica (Vista) (X1)	2008	08	→			24"	600mm	E3	14"	350mm	E3
TOYOTA	Alphard	2008	05	→			28"	700mm	E3	14"	350mm	E3
TOYOTA	Auris (E18)	2012	10	→			26"	650mm	E3	14"	350mm	E3
TOYOTA	Auris Touring Sports (E18)	2013	07	→			26"	650mm	E3	14"	350mm	E3
TOYOTA	Liteace Box (CM3_KM3_V)	1985	10	→	1992	01	22"	550mm	E3	14"	350mm	E3
TOYOTA	Liteace Bus (CM30_G,KM30_G)	1985	10	→	1992	01	22"	550mm	E3	14"	350mm	E3
TOYOTA	Urban Cruiser	2009	01	→			24"	600mm	E3	14"	350mm	E3
TOYOTA	Yaris (P9, JTD)	2005	08	→			24"	600mm	E3	14"	350mm	E3
TOYOTA	Yaris (P9, VNK)	2005	11	→			24"	600mm	E3	14"	350mm	E3
VAUXHALL	KB Pickup	1980	01	→	1981	12	14"	350mm	E3	14"	350mm	E3